

FIG. 1




FIG. 2




FIG. 3A

This screen is titled "Medium specification". It contains four radio button options: "DVD-RAM (4. 7GB)" (selected), "DVD-R (4. 7GB)", "Other", and "Other medium size :". The "Other medium size" option is followed by a small rectangular input field. At the bottom are "Enter" and "Cancel" buttons.

FIG. 3B

This screen displays the "Selected titles" from the previous step. To the right, it shows the "Necessary number of optical disks" as "DVD-RAM (4. 7GB) 2. 6". At the bottom is a large oval button labeled "Confirmation".

FIG. 3C




FIG. 4

Medium specification

- DVD-RAM(4.7GB)
- DVD-R(4.7GB)
- 
- Other medium size :

FIG. 5A

Virtual medium name :

Creation number :

FIG. 5B




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 12




FIG. 10




FIG. 11




FIG. 13